1. Hold the button with **3 horizontal bars** for 5 seconds or until you hear a soft beep > then double click the button to get into desktop mode after it beeps

2. Select **Setup**

Desktop

Setup

3. Select **System Config**

Setup

System Config

4. Select **Network**

System Config   X

Network

5. Select **Next**

Network   X

Enable HTTPS:

ON

Back   Next

6. On the next screen it will ask you to select your network. Select **WLAN.**

Select Network   X

Please select network:

Back   Wired   WLAN

7. Once you select your network you then, select your wifi. Scroll until you find it and select it.

WLAN	X
<< "Select WIFI" >>	
swipe left/right to observe other networks	

Back   Enter SSID   Rescan

8. Enter in your WLAN/WIFI password into the box and select **Next**.

WLAN Password	X

Please enter WLAN Password:

****

Back   Next

9. Select **Next**

Network	X

Network configuration:

Blacklist cleanup   **ON** ⬤

Enable blacklist cleanup.

Back   Next

10. On this screen select the Ping Interval, enter 60, and then select **DHCP**.

Network	X

Network configuration:

HeartBeat   **ON** ⬤

Ping Interval: 60

This option allows to ping gateway at the interval specified above.

DHCP   Static

11. Finally select **Continue**

Continue